

COMPARISON CHART

SECURITY

RF transmitters and receiver

	3500K	3300	3100	2300	1300S	1200K	1100S	1100F	82
No. of buttons	3	3	2	3	3	2	2	2	◆ ¹
SafeCode™ code hopping	◆	◆	◆	◆	◆		◆		
18 quintillion transmitter codes	◆	◆	◆	◆	◆		◆		
68 billion transmitter codes						◆		◆	
RF anti-scan circuitry	◆	◆	◆	◆	◆	◆	◆	◆	
Code-learning	◆	◆	◆	◆	◆	◆	◆		
CodeAway™	◆	◆	◆	◆	◆	◆	◆		
Panic via remote	◆	◆	◆	◆	◆	◆	◆	◆	
Built-in Anti-Carjack security	◆				◆				
All-Time Starter Disable	◆	◆		◆	◆				
Separate horn honk output				(+/-)					(-)
Starter disable output	Relay	(-)	Relay	(-)	Relay	(-)	(-)	(-)	(-)
Second immobilization output	Relay ²								
Dual-stage shock sensor	◆	◆	◆	◆	◆	On-board ³	◆	◆	◆
On-board glass break sensor ²			◆		◆				
SureSense Trigger™	◆	◆	◆	◆					
Flashing parking light output	Relay	Relay	Relay	Relay	Relay	Relay	Relay	Relay	Relay
Arm/disarm/alarm/tamper	◆	◆	◆	◆	◆	◆	◆	◆	◆
Dual output for European cars	◆	◆	◆	◆	◆	◆	◆	◆	◆
Separate alarm & parking light fuses	◆	◆	◆	◆	◆	◆	◆	◆	◆
ExtraHot	◆	◆	◆	◆	◆	◆	◆	◆	◆
Power door lock output	Relays	(+/-)	Relays	(+/-)	(+/-)	(-)	(-)	(-)	
2-step power door unlock output					◆				
Power door lock input									◆ ⁴
Pre-intrusion output	◆	◆	◆	◆	◆	◆	◆	◆	◆
Trigger zone ID thru LED	◆	◆		◆					◆
Trigger history thru LED						◆			
LED lights to show RF reception	◆	◆	◆	◆	◆	◆	◆	◆	
Illuminated entry (domelight) output ⁵	(-)	(-)	(-)	(-)	(-)				
External accessory protection trigger					◆				
Output for pager, strobe light	◆								
Patented Fail-Safe Arming	◆	◆	◆	◆	◆	◆	◆	◆	◆
Patented EasyTest™	◆	◆	◆	◆	◆	◆	◆	◆	◆
Patented Level-II Security™	◆	◆	◆	◆	◆	◆	◆	◆	◆
Patented On-Guard Disarm™	◆	◆		◆	◆		◆	◆	
Smart Disarm ⁶									◆
Enhanced security housing	optional	optional				optional			

RF CONVENIENCE

2nd channel output	◆	◆	◆	◆	◆	◆			
3rd channel output	◆	◆		◆	◆				
Silent arm/disarm thru transmitter	◆	◆	◆	◆	◆	◆	◆	◆	
Zone bypass thru transmitter	◆	◆	◆	◆	◆	◆	◆	◆	◆
Sensor bypass thru transmitter	◆	◆	◆	◆	◆	◆	◆	◆	
Entry delay if transmitter lost	◆	◆			◆		◆	◆	
Lock/unlock doors anytime via remote	◆	◆	◆	◆	◆	◆	◆	◆	◆

PROGRAMMABILITY

Active or passive arming	◆	◆	◆	◆	◆	◆	◆	◆	◆
Chirp or silent arm/disarm	◆	◆	Silent	◆	◆	◆	◆	◆	◆
Door lock/unlock timing	◆	◆	◆	◆	◆	◆	0.4 sec.	0.4 sec.	
Auto or active door lock (passive mode)	◆	◆	◆	◆	◆	◆			
Permanent disarm / auto reararm	◆	◆	◆	◆		◆			
Whispering Chirp™ or regular chirp	◆	◆		◆	Reg.	Reg.	Reg.		
Current and/or switch sensing				◆	◆		◆	◆	◆
Ignition lock/unlock ON/OFF	◆	◆	◆	◆	◆	◆	ON	ON	
SureSense Trigger™ ON/OFF	◆	◆	ON	◆					
All-Time Starter Disable ON/OFF	◆	◆		◆	◆				
Anti-Carjack ON/OFF	◆								

NOTES: (1) AMAX 82 features controlled via factory remote. (2) Connect to ignition or fuel pump. (3) AMAX 1200K has an on-board shock sensor. (4) AMAX 82 automatically learns door lock polarity of keyless entry system of vehicle. (5) Turns domelight ON when alarm disarmed (for AMAX 3300, domelights also flash when alarm is triggered). (6) Upon entering vehicle, locking the car doors arms the alarm while providing 60 seconds to start car.